## Fresh Kiss Beauté by Roquette® PO 500, GA 290, CD 110 & PO 370

BEAUTÉ
Oral care

OC-001-006

Due to the use of **Beauté by Roquette® PO 500**, this alcohol-free oral spray acts on the oral microbiota by reducing the growth of pathogen microorganisms responsible for halitosis. Its is sweetened with two non-cariogenic polyols, **Beauté by Roquette® PO 370 & Beauté by Roquette® PO 160** acting to reduce mouth dryness while **Beauté by Roquette® CD 110** helps to keep breath fresh throughout all the day.

	INCI NAME	COMMERCIAL NAME (SUPPLIER)	% W/W
PHASE A	Aqua	Demineralized water	Up to 100
	Isosorbide	Beauté by Roquette® PO 500 (Roquette)	5.00
	Xylitol	Beauté by Roquette® PO 370 (Roquette)	10.00
	Sorbitol	Beauté by Roquette® PO 160 (Roquette)	10.00
	Hydroxypropyl Cyclodextrin	Beauté by Roquette® CD 110 (Roquette)	1.00
	Mint Flavour	Arome poudre Menthe code 023C301 (colin Ingredients)	1.00
PHASE B	Sodium Benzoate	Microcare NB (Thor)	0.50
	Potassium Sorbate	Microcare KS (Thor)	0.50
PHASE C	CI 42090	FDC Blue 1 (Sensient Cosmetic Technologies)	QS
PHASE D	Gluconolactone	Beauté by Roquette® GA 290 (Roquette)	QS pH 5,8

## **Process**

Cold process

- Phase A: At room temperature disperse Beauté by Roquette® PO 370 and Beauté by Roquette® PO 160 in Aqua, while stirring (defloculator medium speed). Then add Beauté by Roquette® CD 110, Beauté by Roquette® PO 500 and flavour, under gentle agitation.
- 2. Add Phase B into A while stirring (medium speed).
- 3. Add phase C into A+B, under gentle agitation.
- 4. Adjust pH to 5,8 with phase D 10% aqueous solution of Beauté by Roquette® GA 290.

ASPECT	Aqueous blue lotion
рН	5,6 – 5,8
VISCOSITY	NA
STABILITY	1 month at 50°C and 3 months at room temperature and 40°C

The information contained in this document is to the best of our knowledge true and accurate but all instructions, recommendations or suggestions are made without any guarantee. Since the conditions of use are beyond our control, we disclaim any liability for loss and/or damage suffered from use of these data or suggestions. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement. ® Registered trademarks of Roquette Frères